



Instruction Leaflet

V2.0.0

13 August 2008

Allied Vision Technologies GmbH
Taschenweg 2a
D-07646 Stadtroda / Germany



CE conformity

Info

- AVT GUPPY cameras are in conformity with the CE standard and its underlying directions.



- Board level models are delivered without housing. Because housing design is critical to the electromagnetic interference characteristics of a camera, no CE certification tests regarding electromagnetic interference have been performed for board level models. Users who design board level models into their systems should perform appropriate testing regarding electromagnetic interference after the product design is completed.

Technical and ordering info

Info



- Technical information:**
support@alliedvisiontec.com
phone (for Germany): +49 (0)36428 677-270
phone (for USA): +1 978-225-2030
outside Germany/USA: Please check the link for your local dealer.
<http://www.alliedvisiontec.com/partner.html>
- Ordering and commercial information:**
customer-care@alliedvisiontec.com
phone (for Germany): +49 (0)36428 677-230
phone (for USA): +1 978-225-2030
outside Germany/USA: Please check the link for your local dealer.
<http://www.alliedvisiontec.com/partner.html>
Please note order number/text given in the following tables.

GUPPY Instruction Leaflet V2.0.0

2

Scope of delivery

Each camera package consists of the following system components:



AVT Guppy camera



4.5 m 1394a standard cable



Color version:
Jenofilt 217 IR cut filter (built-in)

B/w version:
Only protection glass, no filter (built-in)



5 mm C-Mount adapter



CD with driver and documentation



Optional:
tripod adapter



Optional:
4.5 m 1394a latching cable



Optional: HIROSE
connector for cable
mount HR25 7TP-8S

Figure 1: System components

www

For more accessories visit the AVT website at:
<http://www.alliedvisiontec.com/avt-products/accessories.html>



Camera I/O connector




Figure 2: Camera I/O connector pin assignment

Pin	Signal	Direction	Level	Description
1	Camera Out 1	Out	$U_{out}(high) = 2.4 V \dots 5 V$ $U_{out}(low) = 0 V \dots 0.4 V$	Camera Output 1
2	Camera Out 2	Out	$U_{out}(high) = 2.4 V \dots 5 V$ $U_{out}(low) = 0 V \dots 0.4 V$	Camera Output 2
3	Camera Out 3	Out	$U_{out}(high) = 2.4 V \dots 5 V$ $U_{out}(low) = 0 V \dots 0.4 V$	Camera Output 3
4	Camera In	In	$U_{in}(high) = 2 V \dots 5 V$ $U_{in}(low) = 0 V \dots 0.8 V$	Camera Input
5	RxD RS232	In	RS232	Terminal Receive Data
6	TxD RS232	Out	RS232	Terminal Transmit Data
7	External Power		+8...36 V DC	Power Supply
8	External GND		GND for RS232, GPIOs and ext. power	External Ground for RS232, GPIOs and external power

Table 1: Camera I/O connector pinning

For maximum voltage levels see **Hardware Installation Guide**, Chapter *GUPPY input descriptions*.

Hardware Installation

To install hardware read **Hardware Installation Guide**.

Note You will find this document in the following directory:

- <CD ROM>:\products\cameras-general
- All_HardInst_Vx.y.z_en.pdf



Software Installation

To install software read (depending on your system):

- FirePackage User Guide
- FirePackage64 User Guide
- Fire4Linux User Guide

Note You will find these documents in the following directory:

- <CD ROM>:\products\AVT_FirePackage_x.y.z
- FirePackage_UserGuide_Vx.y.z_en.pdf
 - FirePackage_x64_UserGuide_Vx.y.z_en.pdf
- <CD ROM>:\products\linux



Cautions

Caution **Hot-plug precautions**



- Although FireWire devices can **theoretically** be hot-plugged without powering down equipment, **we strongly recommend turning the computer power off, before connecting a digital camera** to it via a FireWire cable.
- Static electricity or slight plug misalignment during insertion may short-circuit and damage components.**
- The physical ports **may be damaged by excessive ESD** (electrostatic discharge), when connected under powered conditions. It is good practice to ensure proper grounding of computer case and camera case to the same ground potential, before plugging the camera cable into the port of the computer. This ensures that no excessive difference of electrical potential exists between computer and camera.

Latching precautions

- We strongly recommend using only 1394a cables with latch connectors**, to insure a tight electrical connection that is resistant to vibration and gravity.
- We strongly recommend using only 1394b adapter cards with screw-locks.**

Caution



- Make sure **not** to touch the shield of the camera cable connected to a computer and the ground terminal of the lines at the same time.
- If you are charged: before touching the shield of the camera cable, make sure to discharge first (by touching the ground terminal of the lines).
- Use only DC power supplies with insulated cases. These are identified by having **only two** power connectors.
- If you feel uncomfortable with the previous advice or if you have no knowledge about the connectivity of an installation, **we strongly recommend powering down all systems before connecting or disconnecting a camera.**

Safety instructions

Note



- There are no switches or parts inside the camera that require adjustment. The guarantee becomes void upon opening the camera casing.
- If the product is disassembled, reworked or repaired by other than a recommended service person, AVT or its suppliers will take no responsibility for the subsequent performance or quality of the camera.
- The camera does **not** generate dangerous voltages internally. However, because the IEEE 1394a and 1394b standard permit cable power distribution at voltages higher than 24 V, **please note that various country-specific regulations apply.**

Note



- All **color models** are equipped with an **optical filter** to eliminate the influence of infrared light hitting the sensor. Please be advised that, as a side effect, this filter reduces sensitivity in the visible spectrum. The optical filter is part of the back focus ring, which is threaded into the C-Mount.
- B/w models** are delivered with a **sensor protection glass** mounted in the back focus ring to ensure maximum sensitivity. In certain applications and depending on the lighting source and optics, the use of either IR blocking or IR passing filter may be required to improve the image quality.

Caution



- Mount/dismount lenses and filters in a **dust-free environment**, and **do not** use compressed air (which can push dust into cameras and lenses).
- Use only **optical quality tissue/cloth** if you must clean a lens or filter.
- Read Hardware Installation Guide, Chapter Cleaning instructions.**

Environmental conditions

- Housing temperature (when camera in use): + 5 °C ... + 50 °C
- Ambient temperature during storage: - 10 °C ... + 60 °C
- Relative humidity: 20 % ... 80 % without condensation
- Protection: IP 30

Copyright

All texts, pictures and graphics are protected by copyright and other laws protecting intellectual property. It is not permitted to copy or modify them for trade use or transfer, nor may they be used on web sites.

Allied Vision Technologies GmbH 08/2008

All rights reserved.
Managing Director: Mr. Frank Grube
Tax ID: DE 184383113